



## TOOLS

### Aftermarket Intraax & Maxitraax Tooling

### Aftermarket Intraax & Maxitraax Tooling

	PART NO.	APPLICATION AND GENERAL INFORMATION
	00.0800.08	<p><b>Hendrickson Tri-Bushing Replacement Tool in Galvanised Tool Box</b></p> <p>Part Numbers include:</p> <ul style="list-style-type: none"> <li>00.0800.01 Hendrickson Tri-Hex Head Bolt Intraax (1)</li> <li>00.0800.03 Hendrickson Tri-Front Plate Intraax (1)</li> <li>00.0800.04 Hendrickson Tri-Transition Tube Intraax (1)</li> <li>00.0800.05 Hendrickson Tri-Cup Intraax (1)</li> <li>00.0800.06 Hendrickson Tri-Removal Spacer</li> <li>00.0800.07 Hendrickson Tri- Rear Drive Plate Intraax (1)</li> <li>00.0800.10 Timkin Thrust Bearing (1)</li> <li>00.0800.11 M30 Grade 8 Flat Washer Black (4)</li> <li>00.0800.12 Screw PLN Cup M12x50mm Long Intraax (2)</li> <li>00.0800.13 Screw PLN Cup M12 x 100mm Long Intraax (2)</li> <li>00.0800.14 Galvanised Tool Box (1)</li> </ul>
	00.0801.08	<p><b>Hendrickson Maxitraax Bushing Replacement Tool in Galvanised Tool Box</b></p> <p>Part Numbers include:</p> <ul style="list-style-type: none"> <li>00.0800.01B Hendrickson Tri-Hex Head Bolt Maxitraax (1)</li> <li>00.0800.03B Hendrickson Tri-Front Plate Maxitraax (1)</li> <li>00.0800.04B Hendrickson Tri-Transition Tube Maxitraax (1)</li> <li>00.0800.06 Hendrickson Tri-Removal Spacer</li> <li>00.0800.07B Hendrickson Tri- Rear Drive Plate Maxitraax (1)</li> <li>00.0800.10 Timkin Thrust Bearing (1)</li> <li>00.0800.11 M30 Grade 8 Flat Washer Black (4)</li> <li>00.0800.14 Galvanised Tool Box (1)</li> <li>00.0800.15 Hendrickson Maxitraax–Rear Drive Plate Pins (4)</li> </ul>